



# Membrane Leak Detection Sensor

## EM300-MLD

### User Guide

# Contents

|  |           |
|--|-----------|
| <b>Chapter 1. Introduction.....</b>            | <b>4</b>  |
| Copyright Statement.....                       | 4         |
| Safety Instruction.....                        | 4         |
| Services.....                                  | 4         |
| Revision History.....                          | 5         |
| <b>Chapter 2. Production Introduction.....</b> | <b>6</b>  |
| Overview.....                                  | 6         |
| Features.....                                  | 6         |
| <b>Chapter 3. Hardware Introduction.....</b>   | <b>7</b>  |
| Packing List.....                              | 7         |
| Hardware Overview.....                         | 7         |
| Dimensions (mm).....                           | 7         |
| Power Button.....                              | 8         |
| <b>Chapter 4. Quick Start.....</b>             | <b>9</b>  |
| Water Leakage Testing.....                     | 9         |
| <b>Chapter 5. Operation Guide.....</b>         | <b>11</b> |
| LoRaWAN Settings.....                          | 11        |
| General Setting.....                           | 13        |
| Time Synchronization.....                      | 15        |
| Water Leakage Alarm.....                       | 16        |
| Milesight D2D Setting.....                     | 16        |
| Maintenance.....                               | 18        |
| Upgrade.....                                   | 18        |
| Backup and Restore.....                        | 19        |
| Reset to Factory Default.....                  | 21        |
| <b>Chapter 6. Installation.....</b>            | <b>23</b> |
| EM300 Device Installation.....                 | 23        |

|   |           |
|---|-----------|
| Membrane Installation.....                    | 24        |
| <b>Chapter 7. Battery Replacing.....</b>      | <b>26</b> |
| <b>Chapter 8. Communication Protocol.....</b> | <b>27</b> |
| Overview.....                                 | 27        |
| Uplink Data.....                              | 27        |
| Basic Information.....                        | 27        |
| Periodic Report.....                          | 28        |
| Alarm Report.....                             | 28        |
| Historical Data.....                          | 29        |
| Downlink Command.....                         | 29        |
| General Setting.....                          | 29        |
| Alarm Setting.....                            | 30        |
| D2D Setting.....                              | 31        |
| Historical Data Enquiry.....                  | 31        |

# Chapter 1. Introduction

## Copyright Statement

This guide may not be reproduced in any form or by any means to create any derivative such as translation, transformation, or adaptation without the prior written permission of Xiamen Milesight IoT Co., Ltd (Hereinafter referred to as Milesight).

**Milesight** reserves the right to change this guide and the specifications without prior notice. The latest specifications and user documentation for all Milesight products are available on our official website <http://www.milesight.com>

## Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss. Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.



### **CAUTION:**

Injury or equipment damage may be caused if any of these cautions are neglected.

- The device is not intended to be used as a reference sensor, and Milesight will not should responsibility for any damage which may result from inaccurate readings.
- The device must not be disassembled or remodeled in any way.
- Do not place the device close to objects with naked flames.
- Do not place the device where the temperature is below/above the operating range.
- Make sure electronic components do not drop out of the enclosure while opening.
- When installing the battery, please install it accurately, and do not install the reverse or wrong model.
- The device must never be subjected to shocks or impacts.
- In order to protect the security of the device, please change device password when first configuration. The default password is 123456.

## Services

Milesight provides customers with timely and comprehensive technical support services. End-users can contact your local dealer to obtain technical support. Distributors and resellers can contact directly with Milesight for technical support.

Technical Support Mailbox: [iot.support@milesight.com](mailto:iot.support@milesight.com)

Online Support Portal: <https://support.milesight-iot.com>

Resource Download Center: <https://www.milesight.com/iot/resources/download-center/>

**MILESIGHT CHINA**

TEL: +86-592-5085280

FAX: +86-592-5023065

Add: Building C09, Software Park Phase III, Xiamen 361024, Fujian, China

## Revision History

| Release Date     | Version | Revision Content |
|------------------|---------|------------------|
| October 31, 2023 | V1.0    | Initial version  |

# Chapter 2. Production Introduction

## Overview

EM300-MLD is an innovative leak sensor that incorporates a flexible printed membrane. This design enables precise detection and customized coverage in a compact form factor, making it suitable for various applications. With a single embedded battery, EM300-MLD offers a long operational life of up to 10 years, extendable to two batteries if desired. Its high IP67 protection and durable construction ensure reliability and adaptability in harsh environments.

With easy configuration and wireless detection, the EM300-MLD facilitates simple deployment and connectivity. Compliant with Milesight LoRaWAN<sup>®</sup> gateway and Milesight Development Platform solution, users can monitor the leakage and receive alarms easily via webpage remotely.

## Features

- Detect the presence of liquids by a flexible printed membrane for covering a larger area
- Equip with high-quality printed membrane that can be reused and customized
- Adopt green material with 100% reusability and cause no dangerous emissions
- Ultra-wide-distance transmission up to line of sight of 10km
- IP67 UV-resistant and waterproof enclosure for harsh environment applications
- Built-in 4000 mAh replaceable battery and works for more than 10 years without replacement
- Store locally 1, 000 historical records and support retransmission to prevent data loss
- Support Milesight D2D protocol to enable ultra-low latency and direct control without gateways
- Equipped with NFC for easily configuration
- Compliant with standard LoRaWAN<sup>®</sup> gateways and network servers
- Quick and easy management with Milesight IoT Cloud or Milesight Development Platform


# Chapter 3. Hardware Introduction

## Packing List



1 × EM300-MLD Device

(Include detection membrane)



2 × Wall Mounting Kits



2 × Screw Caps



1 × Quick Guide




1 × Warranty Card




### Note:

If any of the above items is missing or damaged, please contact your sales representative.


## Hardware Overview



Waterproof Connector



## Dimensions (mm)



## Power Button


There is a LED indicator and a power button inside the device for emergency reboot or reset.


| Function                 | Action  | LED Indicator             |
|--------------------------|---|---------------------------|
| Power On                 | Press and hold the button for more than 3 seconds.  | Off → On                  |
| Power Off                |   | On → Off                  |
| Reset to Factory Default | Press and hold the button for more than 10 seconds. | Blinks quickly            |
| Check On/Off Status      | Quickly press the power button once.                | Light On: device is on.   |
|                          |   | Light Off: device is off. |



## Chapter 4. Quick Start

This chapter describe the steps to quickly configure this device. If you requires more advanced settings, please refer to operation guide chapter.

1. Download and install “Milesight ToolBox” App from Google Play or Apple Store on an NFC-supported smartphone.
2. Enable NFC function on the smartphone, launch Milesight ToolBox, and select the default mode as NFC.
3. Attach the smart phone with NFC area to the device and click  to read device information.



4. Click power button on the ToolBox App and attach the smartphone to device to power on the device.
5. Keep other settings by default or change as required, then attach the smartphone with NFC area to the device and click **Write** to write the settings. After writing, reread the device to check if the configuration is written well.



### Note:

Set the channel index as 8-15 for US915 or AU915 if using default settings of Milesight gateways.

## Water Leakage Testing




1. Go to **Device > General** page to set reporting interval as 1 minute.
2. [Connect the membrane to EM300 device \(on page 24\)](#), then remove the protective film on the detection side.
3. Put the membrane into enough water.
4. Wait for more than 1 minute, then read the device to check if the leakage status changes to **Leaked**.


5. Dry the membrane with soft cloth.
6. Wait for more than 1 minute, then read the device to if the leakage status changes to **No leak**.

# Chapter 5. Operation Guide

## LoRaWAN Settings

This chapter describes the LoRaWAN<sup>®</sup> network settings of device.


| Parameter                    | Description   |
|------------------------------|---|
| Device EUI                   | Unique ID of the device which can be found on the device.<br><div> <b>Note:</b><br/>please contact sales for device EUI list if you have many units.</div>   |
| App EUI                      | The default App EUI (join EUI) is 24E124C0002A0001.   |
| Application Port             | The port used for sending and receiving data, the default port is 85.   |
| LoRaWAN <sup>®</sup> Version | V1.0.2 and V1.0.3 are available.  |
| Work Mode                    | It's fixed as Class A.  |
| Confirmed Mode               | If the device does not receive ACK packet from network server, it will re-send data once.   |
| Join Type                    | OTAA and ABP mode are available.<br><div> <b>Note:</b><br/>it's necessary to select OTAA mode if connecting device to Mile-sight IoT Cloud or Milesight Development Platform.</div>              |
| Application Key              | Appkey for OTAA mode, the default is 5572404C696E6B4C6F52613230313823.<br><div> <b>Note:</b><br/>please contact sales if you require random App Keys for bulks of devices before purchase.</div> |
| Network Session Key          | Nwkskey for ABP mode, the default is 5572404C696E6B4C6F52613230313823.  |
| Application Session Key      | Appskey for ABP mode, the default is 5572404C696E6B4C6F52613230313823.  |



| Parameter           | Description  |
|---------------------|--|
| Device Address      | DevAddr for ABP mode, default is the 5 <sup>th</sup> to 12 <sup>th</sup> digits of SN.   |
| Rejoin Mode         | <p>Reporting interval ≤ 35 mins: the device will send a specific number of Link-CheckReq MAC packets to the network server every reporting interval or every double reporting interval to validate connectivity; If there is no response, the device will re-join the network.</p> <p>Reporting interval &gt; 35 mins: the device will send a specific number of LinkCheckReq MAC packets to the network server every reporting interval to validate connectivity; If there is no response, the device will re-join the network.</p> <div>  <b>Note:</b> <ol style="list-style-type: none"> <li>1. Only OTAA mode supports rejoin mode.</li> <li>2. The actual sending number is <b>Set the number of packets sent + 1</b>.</li> </ol> </div> |
| Supported Frequency | <p>Enable or disable the frequency to send uplinks. If frequency is one of CN470/AU915/US915, enter the index of the channel to enable in the input box, making them separated by commas.</p> <p><b>Examples:</b></p> <p>1, 40: Enabling Channel 1 and Channel 40</p> <p>1-40: Enabling Channel 1 to Channel 40</p> <p>1-40, 60: Enabling Channel 1 to Channel 40 and Channel 60</p> <p>All: Enabling all channels</p> <p>Null: Indicate that all channels are disabled</p>  |
| ADR Mode            | Enable or disable network server to adjust Spreading Factor, Bandwidth and Tx Power to optimize data rates, airtime and energy consumption in the network.   |
| Spreading Factor    | If ADR mode is disabled, the device will send uplink data following this SF parameter. The higher the spreading factor, the longer the transmission distance, the slower the transmission speed and the more the consumption.  |

| Parameter     | Description  |
|---------------|--|
| Tx Power      | Tx power (transmit power) refers to the strength of the outgoing signal transmitted by the device. This is defined by LoRa alliance. |
| RX2 Data Rate | RX2 data rate to receive downlinks.  |
| RX2 Frequency | RX2 frequency to receive downlinks. Unit: Hz   |

## General Setting

General settings include the basic parameters of the device.

| Parameter          | Description   |
|--------------------|---|
| Reporting Interval | The interval to report current data to network server. Range: 1-1080 minutes, Default: 1080 minutes.  |
| Data Storage       | <p>Disable or enable to store <b>periodic report</b> data locally. The stored data can be exported as CSV format file and saved to smartphone via Tool-Box.</p>  <p>The screenshot shows the 'Device Maintenance' screen with a 'History Data' option highlighted. Below the screen, a 'Maintenance' button is highlighted. A dashed arrow points from the 'History Data' option to a 'History Data' export screen. The export screen shows a date range selector and a note: 'The time range for exporting data is 14 days, if it exceeds the time range, it cannot be exported.' There are 'Clear All' and 'Export' buttons at the bottom of the export screen.</p> |


| Parameter           | Description   |
|---------------------|---|
|                     | <div data-bbox="574 275 1390 682">  <b>Note:</b> <ol style="list-style-type: none"> <li>1. It is necessary to <a href="#">sync the time (on page 15)</a> to ensure the data is stored in correct time.</li> <li>2. The device will still store the data even the network status is de-activated.</li> <li>3. ToolBox App can only export the last 14 days' data at most.</li> </ol> </div>   |
| Data Retransmission | <p data-bbox="557 716 1391 884">Disable or enable data retransmission. When the device detects the network status is de-activated via <a href="#">Rejoin Mode (on page 12)</a>, the device will record a data lost time point and re-transmit the lost data after device re-connects to the network.</p> <div data-bbox="574 921 1390 1749">  <b>Note:</b> <ol style="list-style-type: none"> <li>1. This setting only takes effect when <a href="#">Data Storage (on page 13)</a> is enabled.</li> <li>2. If the device is rebooted or re-power when data retransmission is not completed, the device will re-send all retransmission data again after device is reconnected to the network.</li> <li>3. If the network is disconnected again during data retransmission, it will only send the latest disconnected data.</li> <li>4. The default report data retransmission interval is 600s, this can be changed via downlink command.</li> <li>5. The reported format of retransmission data will include timestamps and is different from periodic report data.</li> <li>6. This setting will increase the uplink frequencies and shorten the battery life.</li> </ol> </div> |
| Change Password     | Change the device password for ToolBox App to write this device.  |

# Time Synchronization

This section describes how to sync the time of the device.

## Sync via ToolBox App

After reading the device via Milesight ToolBox App, sync the device time with time zone from the smart phone.



## Sync via Network Server

This requires to ensure the LoRaWAN<sup>®</sup> network server supports device time synchronization feature. Example: Milesight gateway embedded NS.

1. Set the LoRaWAN<sup>®</sup> version of the device to V1.0.3.
2. Connect the device to the network server. After joining the network, the device will send a DeviceTimeReq MAC command to enquire the time from network server.



### Note:

- This only supports to get the time but not time zone. The time zone can be configured by ToolBox App or downlink command.
- The device will send the DeviceTimeReq command every 5 days since the last sync.

## Water Leakage Alarm

The device will report the alarm packets according to the alarm reporting interval and alarm reporting times when it detects the water leaked. Only when the alarm is dismissed and re-triggered, the device will send the alarm again.

| Parameter                | Description   |
|--------------------------|---|
| Alarm Reporting Interval | The interval to report alarm packet after alarm triggers. |
| Alarm Reporting Times    | Alarm packet report times after alarm triggers.           |

Device

Network

Calibration

Threshold

Alarm

...

Alarm Reporting

☒

If water leakage occurs, the alarm reporting interval and the alarm reporting times can be set as follows

Alarm Reporting Interval

-

1

+

mi

Alarm Reporting Times

-

2

+

## Milesight D2D Setting

Milesight D2D protocol is developed by Milesight and used for setting up transmission among Milesight devices without gateway. When the Milesight D2D settings is enabled, the device can work as a D2D controller to send control commands to trigger Milesight D2D agent devices.

**Step 1:** Configure the RX2 datarate and RX2 frequency.



**Note:**

It is suggested to change the default values if there are many LoRaWAN<sup>®</sup> devices around.



Device

Network

LoRaWAN

D2D

Spreading Factor ⓘ

SF12-DR0

TXPower

TXPower0-16 dBm

RX2 Data Rate ⓘ

DR0 (SF12, 125 kHz)

RX2 Frequency ⓘ

869525000

**Step 2:** Enable the threshold alarm settings and configure related parameters.

**Step 3:** Enable Milesight D2D feature and define an unique D2D key which is the same as Milesight D2D agent devices. (Default D2D key: 5572404C696E6B4C6F52613230313823)

Device

Network

LoRaWAN

D2D

Enable

☒

D2D Key

\*\*\*\*\*

**Step 4:** Enable one of statuses and configure 2-byte hexadecimal Milesight D2D command.

**Note:**

If you enable **LoRa Uplink**, a LoRaWAN<sup>®</sup> uplink packet that contains corresponding alarm status will be sent to gateway after the Milesight D2D command packet. Otherwise, the alarm packet will not send to LoRaWAN<sup>®</sup> gateway.

**Example:** When the water is leaked, the device will send command ff01 to D2D agent devices.

Sensor Status: Leak ☒

Control command

ff01

LoRa Uplink ⓘ ☐

## Maintenance

### Upgrade

This chapter describe the steps to upgrade the device via ToolBox App.

#### Upgrade via NFC


**Step 1:** Download firmware from Milesight official website to your smartphone.

**Step 2:** Launch ToolBox App, click **Upgrade** to upload the firmware file.

**Step 3:** Click **Upgrade** to upgrade the device.

**Note:**

- Operation on ToolBox is not supported during an upgrade.
- Only Android version ToolBox supports the upgrade feature.




## Backup and Restore

This device supports configuration backup for easy and quick device configuration in bulks. Backup and restore is allowed only for devices with the same model and frequency band.

### Backup and Restore

**Step 1:** Launch ToolBox App, attach the NFC area of smartphone to the device to read the configuration.


**Step 2:** Edit the configuration as required, click **Set Template** to save current configuration as a template to the ToolBox App.



**Step 3:** Go to **Device >Template** page.




**Step 4:** Select and click the target template, click **Write** to import the configuration to target devices.



### Export and Delete Template

**Step 1:** Check the box of the target template.


**Step 2:** Click **Export** to export this template as JSON format file and save it to the smartphone, click **Delete** to delete this template from your ToolBox App.



### Reset to Factory Default

**Via Hardware:** Hold on the reset button for more than 10s until the LED indicator quickly blinks.

**Via ToolBox App:** Click **Reset** and attach the smartphone to device to reset the device.



# Chapter 6. Installation

## EM300 Device Installation

### Installation Location

Keep the device away from metal objects and obstacles.


### Wall Mounting

**Step 1:** Attach EM300 device to the wall and mark the two holes on the wall. The connecting line of two holes must be a horizontal line.

**Step 2:** Drill the holes according to the marks and screw the wall plugs into the wall.

**Step 3:** Mount the EM300 to the wall via mounting screws.


**Step 4:** Cover the mounting screws with screw caps.



Besides, it can also be mounted to the wall via a 3M tape.

### Pole Mounting

Pass the cable tie through the mounting holes of the device and wrap the device to the pole.




## Membrane Installation

The detection membrane has two sides: one side with black printed lines to detection water leakage, the other side with 3M tape to paste as required. When the water covers two black lines (soaking water length > 1.5 cm), the device will trigger the leakage alarms.

### Installation Locations


Usually the membrane can be placed under the electrical appliances (refrigerator, washing machine, etc.), while the EM300-MLD and connector can be fixed on the adjacent wall.



To ensure the most sensitive effect, ensure the installation location is a flat surface without debris, dust and deep gaps. If the membrane needs to be pasted to installation location, the surfaces should be cleaned and free from dirt, adhesive residue, water drops and other things.

### Connect the Membrane to EM300 Device

Slide one of the tabs sticking out from the membrane into the connector of EM300-MLD device, ensure the black lines touch the two metal parts of the connector, then restore the connector cover back to fix the membrane into device.



### Install the Membrane




**Step 1:** Cut the membrane to suit the detection area or keep the whole membrane without cutting. It is necessary to cut the membrane as below direction to avoid the black lines disconnected.



**Note:**

One membrane has two connection tabs and supports to be cut as two pieces for two EM300-MLD devices. If you only use one tab and the other tab is useless, you can also cut it.



**Step 2:** Remove the protective film on the detection side.

**Step 3:** Put the membrane on the installation location, ensure the detection side touches the detection area or detection object, the membrane is placed flat without crimping.

Besides, you can tear the other side to paste the membrane to the wall via 3M tape.

## Maintenance

After removing the membrane from the leakage location, dry the detection side with a soft cloth and ensure the leakage status back to “No Leak”. The membrane can be reused in other places.




**Note:**

Do not rub off the black lines on the detection side, as this can reduce leakage detection sensitivity or even disable the leakage detection feature.

## Chapter 7. Battery Replacing

When the batteries have run out of power, please remove the back cover to replace the new batteries.



### Note:

- EM300 provides 4000mAh version and 8000mAh version. Please do not install 2 batteries on the 4000mAh version, and vice versa. Otherwise, it will cause inaccurate power calculations.
- To reduce the interference of NFC transmission, it is suggested that the battery be installed in the upper location (see figure).
- The device can only be powered by the ER18505 Li-SoCl<sub>2</sub> battery. The alkaline battery is not supported.
- The battery should be removed or replaced from the device if it is not used for an extended period.
- Ensure all replacing batteries are newest; otherwise, it may shorten battery life or cause inaccurate power calculations.

# Chapter 8. Communication Protocol

## Overview

All messages are based on following format (HEX), the Data field should follow little-endian:

| Channel1 | Type1  | Data1   | Channel2 | Type2  | Data2   | Channel3 | ... |
|----------|--------|---------|----------|--------|---------|----------|-----|
| 1 Byte   | 1 Byte | N Bytes | 1 Byte   | 1 Byte | N Bytes | 1 Byte   | ... |

For decoder examples please find files on <https://github.com/Milesight-IoT/SensorDecoders>.

## Uplink Data

This chapter describes the reported data of the device.

| Item             | Channel | Type | Byte | Description  |
|------------------|---------|------|------|--|
| Power On         | ff      | 0b   | 1    | Device is on   |
| Protocol Version | ff      | 01   | 1    | Example: 01=V1   |
| Hardware Version | ff      | 09   | 2    | Example: 03 10 = V3.1  |
| Software Version | ff      | 0a   | 2    | Example: 03 01 = V3.1  |
| Device Type      | ff      | 0f   | 1    | 00: Class A, 01: Class B, 02: Class C, 03: Class C to B  |
| Serial Number    | ff      | 16   | 8    | 16 digits  |
| Battery Level    | 01      | 75   | 1    | UINT8, Unit: %   |
| Water Leakage    | 05      | 00   | 1    | 00: Not leak, 01: Leaked   |
| Historical Data  | 20      | ce   | 8    | <b>Byte 1-4:</b> Data unix timestamp, UINT32, Unit: s<br><b>Byte 5-7:</b> 000000<br><b>Byte 8:</b> Leakage status, 00=no leak, 01=leak |

### Basic Information

The device will report a basic information packet whenever joining the network.

**Example:**

| ff0bff ff0101 ff166136c40091605408 ff090300 ff0a0101 ff0f00 |      |                  |
|---|------|------------------|
| Channel   | Type | Value            |
| ff  | 0b   | ff               |
| ff  | 01   | 01=V1            |
| ff  | 16   | 6136c40091605408 |
| ff  | 09   | 0300=V3.0        |
| ff  | 0a   | 0101=V1.1        |
| ff  | 0f   | 00: Class A      |

## Periodic Report

The device supports to report below types of periodic report packets.

1. Sensor data: report according to reporting interval.

| 050000  |      |              |
|---------|------|--------------|
| Channel | Type | Value        |
| 05      | 00   | 00: Not leak |

2. Battery level: report when the device joins the network or every 6 hours.

| 017564  |      |                   |
|---------|------|-------------------|
| Channel | Type | Value             |
| 01      | 75   | Battery: 64=>100% |

## Alarm Report

The device supports to report below types of alarm report packets.

1. Water leakage alarm or alarm dismiss: report when alarm reporting feature is enabled.

| 050001  |      |            |
|---------|------|------------|
| Channel | Type | Value      |
| 05      | 00   | 01: Leaked |

2. Low battery level alarm: report when battery level is below to 1%.

| 017501  |      |                 |
|---------|------|-----------------|
| Channel | Type | Value           |
| 01      | 75   | Battery: 01=>1% |

## Historical Data

The device will report retransmission data or stored data as below example.

| 20ce 0d755b63 000000 00 |      |   |                            |
|-------------------------|------|---|----------------------------|
| Channel                 | Type | Time Stamp                                | Value                      |
| 20                      | ce   | 0d 75 5b 63 => 63 5b<br>75 0d=1666938125s | Leakage status: 00=no leak |

## Downlink Command

This device supports downlink commands for configuration and control. The downlink application port is 85 by default.

### General Setting

| Item                         | Channel | Type | Byte | Description   |
|------------------------------|---------|------|------|---|
| Reboot                       | ff      | 10   | 1    | ff  |
| Collect Interval             | ff      | 02   | 2    | UINT16, Unit: s   |
| Report Interval              | ff      | 03   | 2    | UINT16, Unit: s   |
| Data Storage                 | ff      | 68   | 1    | 00: Disable, 01: Enable   |
| Data Retransmission          | ff      | 69   | 1    | 00: Disable, 01: Enable   |
| Data Retransmission Interval | ff      | 6a   | 3    | <b>Byte 1:</b> 00<br><b>Byte 2-3:</b> UINT16, Unit: s, Range: 30~1200, Default: 600 |

**Example:**

1. Reboot the device.

|        |
|--------|
| ff10ff |
|--------|

2. Set collect interval as 20 minutes.

| ff02b004 |      |                             |
|----------|------|-----------------------------|
| Channel  | Type | Value                       |
| ff       | 02   | b004=>04b0=1200s=20 minutes |

3. Set report interval as 20 minutes.

| ff03b004 |      |                             |
|----------|------|-----------------------------|
| Channel  | Type | Value                       |
| ff       | 03   | b004=>04b0=1200s=20 minutes |

## Alarm Setting

| Channel | Type | Byte | Description   |
|---------|------|------|---|
| ff      | 06   | 9    | <b>Byte 1:</b> 10=Disable, 11=Enable<br><b>Byte 2-5:</b> 00000000<br><b>Byte 6-7:</b> Alarm reporting interval, unit: s<br><b>Byte 8-9:</b> Alarm reporting times |

### Example:

Enable alarm and set alarm reporting interval as 1 minute and alarm reporting times as 2.

| ff0611000000003c000200 |      |  |
|------------------------|------|--|
| Channel                | Type | Value  |
| ff                     | 06   | 11=Enable<br>3c00=>003c=60s=1 minute<br>0200=>0002=2 |

## D2D Setting

| Channel | Type | Byte | Description   |
|---------|------|------|---|
| ff      | 79   | 4    | <b>Byte 1:</b><br>03=Leak, 04=No Leak<br><b>Byte 2:</b> 00=Disable, 01=Only D2D, 03=D2D & LoRa Uplink<br><b>Byte 3-4:</b> D2D Command |

### Example:

When water is leaked, send D2D command 0110.

| ff7901031001 |      |  |
|--------------|------|--|
| Channel      | Type | Value  |
| ff           | 79   | 03=Leaked<br>01=Only D2D<br>D2D Command: 10 01=>0110 |

## Historical Data Enquiry

The device supports data retrievability feature to send downlink command to enquire the historical data stored in the device. Before that, ensure the device time is correct and data storage feature was enabled to store data.

### Command Format:

| Item                       | Channel | Type | Byte | Description  |
|----------------------------|---------|------|------|--|
| Enquire Data in Time Point | fd      | 6b   | 4    | Unix timestamp, Unit: s  |
| Enquire Data in Time Range | fd      | 6c   | 8    | Byte 1-4: Start timestamp, Unit: s<br>Byte 5-8: End timestamp, Unit: s |
| Stop Query Data Report     | fd      | 6d   | 1    | ff   |
| Data Retrieval Interval    | ff      | 6a   | 3    | Byte 1: 01   |

| Item | Channel | Type | Byte | Description  |
|------|---------|------|------|--|
|      |         |      |      | Byte 2-3: UINT16, Unit: s, Range: 30~1200, Default: 60 |

**Reply Format:**

| Item           | Channel | Type  | Byte | Description  |
|----------------|---------|-------|------|--|
| Enquiry Result | fc      | 6b/6c | 1    | 00: Enquiry success. The device will report the historical data according to data retrievability interval.<br>01: Time point or time range invalid<br>02: No data in this time or time range |

**Note:**

1. Use [Unix Timestamp Converter](#) to calculate the time.
2. The device only uploads no more than 300 data records per range enquiry.
3. When enquiring the data in time point, it will upload the data which is closest to the search point within the reporting interval range. For example, if the device's reporting interval is 10 minutes and users send command to search for 17:00's data, if the device find there is data stored in 17:00, it will upload this data; if not, it will search for data between 16:50 to 17:10 and upload the data which is closest to 17:00.

**Example:**

Enquire the historical data in a time range.

| fd6c 64735b63 7c885b63 |      |  |
|------------------------|------|--|
| Channel                | Type | Value  |
| fd                     | 6c   | Start time: 64 73 5b 63 => 63 5b 73 64 = 1666937700s<br>End time: 7c 88 5b 63 => 63 5b 88 7c = 1666943100s |

Reply:



| fc6c00  |      |                     |
|---------|------|---------------------|
| Channel | Type | Value               |
| fc      | 6c   | 00: Enquiry success |

| 20ce 0d755b63 000000 00 |      |   |                            |
|-------------------------|------|---|----------------------------|
| Channel                 | Type | Time Stamp                                | Value                      |
| 20                      | ce   | 0d 75 5b 63 => 63 5b<br>75 0d=1666938125s | Leakage status: 00=no leak |