



# LoRaWAN<sup>®</sup> Solenoid Valve Controller

## UC51x Series

User Guide




## Safety Precautions

Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.

- ❖ The device must not be remodeled in any way.
- ❖ Do not place the device close to objects with naked flames.
- ❖ Do not place the device where the temperature is below/above the operating range.
- ❖ Make sure electronic components do not drop out of the enclosure while opening.
- ❖ When installing the battery, please install it accurately, and do not install the reverse or wrong model.
- ❖ The device must never be subjected to shocks or impacts.


## Declaration of Conformity

UC51x series is in conformity with the essential requirements and other relevant provisions of the CE, FCC, and RoHS.



Copyright©2011-2022 Milesight. All rights reserved.

All information in this guide is protected by copyright law. Whereby, no organization or individual shall copy or reproduce the whole or part of this user guide by any means without written authorization from Xiamen Milesight IoT Co., Ltd.



For assistance, please contact

Milesight technical support:

Email: [iot.support@milesight.com](mailto:iot.support@milesight.com)

Tel: 86-592-5085280

Fax: 86-592-5023065

Address: Building C09, Software Park III,  
Xiamen 361024, China

## Revision History

Date	Doc Version	Description
Feb. 20, 2021	V 1.0	Initial version

# Contents

1. Product Introduction.....	4
1.1 Overview.....	4
1.2 Features.....	4
2. Hardware Introduction.....	4
2.1 Packing List.....	4
2.2 Hardware Overview.....	5
2.3 Power Button.....	5
2.4 Dimensions.....	6
3. Installation.....	6
4. Operation Guide.....	7
4.1 Log in the ToolBox.....	7
4.1.1 NFC Configuration.....	7
4.1.2 USB Configuration.....	9
4.2 Solenoid Valve Control.....	10
4.3 LoRaWAN Settings.....	11
4.4 Solenoid Settings.....	13
4.5 Maintenance.....	14
4.5.1 Upgrade.....	14
4.5.2 Backup.....	16
4.5.3 Reset to Factory Default.....	17
5. Milesight IoT Cloud Management.....	18
5.1 Add UC51x to Cloud.....	18
5.2 Solenoid Valve Control.....	20
6. Device Payload.....	22

# 1. Product Introduction

## 1.1 Overview

UC51x series LoRaWAN® wireless solenoid valve controller is a device used to remotely control DC latching solenoids of the valve. It contains 2 solenoid interfaces and 1 pulse interface, which can be easily controlled locally or remotely.


Besides ultra-low-power LoRaWAN® technology, UC51x series also provides both solar and built-in battery power supply for uninterrupted operation. For outdoor applications, it equips with IP67-rated enclosure and M12 connectors to protect from water and dust under harsh environments.

## 1.2 Features


- Compatible with standard DC latching solenoids
- OPEN/CLOSE control by mobile App locally or commands remotely
- Two pulse water meter interfaces for flow monitoring
- Transmission distance up to 11 km with line of sight
- Waterproof design including IP67 case and M12 connectors
- Solar powered and built-in chargeable battery
- Quick wireless configuration via NFC
- Time and flow control via Milesight IoT Cloud

# 2. Hardware Introduction


## 2.1 Packing List



1 × UC51x Device



3 × Data Cables  
(1.5m)



1 × Mounting  
Bracket




Wall Mounting Kits



1 × Warranty Card



1 × Quick Guide



1 × Solar Panel Kit  
(UC511 Optional)




2 × Hose Clamps  
(Optional)




**If any of the above items is missing or damaged, please contact your sales Representative.**

## 2.2 Hardware Overview




### Solenoid Interfaces:

Pin	Description
1	Reserved
2	Reserved
3	CLOSE(Black)
4	OPEN(Red)



### Pulse Interface/DC:


Pin	Description
1	GPIO2
2	VCC(5-24V)
3	GND
4	GPIO1
5	GND
6	GND



## 2.3 Power Button

Function	Action	LED Indication
Turn On	Press and hold the button for more than 3s.	Off → On
Turn Off	Press and hold the button for more than 3s.	On → Off
Reset	Press and hold the button for more than 10s.	Blinks.
Check On/Off Status	Quickly press the power button.	Light On: Device is on.
		Light Off: Device is off.

## 2.4 Dimensions(mm)




## 3. Installation

### Wall Mounting

Make sure you have wall mounting bracket, bracket mounting screws, wall plugs, wall mounting screws and other required tools.

#### Steps:


1. Mount the enclosure to the mounting bracket with the bracket mounting screws.



2. Align the mounting bracket horizontally to the desired position on the wall, use a marker pen to mark four mounting holes on the wall, and then remove the mounting bracket from the wall.

**Note:** The connecting lines of adjacent points are at right angles.

3. Drill the four holes by using your drill with a 6 mm drill bit on the positions you marked previously on the wall.
4. Insert four wall plugs into the holes respectively.
5. Mount the mounting bracket horizontally to the wall by fixing the wall mounting screws into the wall plugs.




## Pole Mounting


Make sure you have wall mounting bracket, bracket mounting screws, hose clamp and other required tools.

### Steps:


1. Mount the enclosure to the mounting bracket with the bracket mounting screws.



2. Loosen the hose clamp by turning the locking mechanism counter-clockwise.



3. Straighten out the hose clamp and slide it through the rectangular holes in the mounting bracket, wrap the hose clamp around the pole.
4. Use a screwdriver to tighten the locking mechanism by turning it clockwise.




## 4. Operation Guide

### 4.1 Log in the ToolBox

UC51x series can be monitored and configured via ToolBox APP or ToolBox software. Please select one of them to complete configuration.

#### 4.1.1 NFC Configuration

1. Download and install "Milesight ToolBox" App from Google Play or Apple App Store.
2. Enable NFC on the smartphone and launch Milesight ToolBox.
3. Attach the smartphone with NFC area to the device to read basic information.



4. Basic information and settings of devices will be shown on ToolBox if it's recognized successfully. You can turn on/off the device by tapping the button on the Device Status. In order to protect the security of devices, password validation is required when first configuration. Default password is **123456**.

Status	Setting	Reset
SN	6415A51585070020	
Model	UC512-DI-868M	
Device EUI	24e124415a515850	
Firmware Version	V1.8	
Hardware Version	V1.0	
Device Status	Off	<input type="checkbox"/>

Read

Device

Template

5. Tap "Read" button to check current status of device.
6. Tap "Write" button to write all your settings to the device.


**Note:**

- 1) Ensure the location of smartphone NFC area and it's recommended to take off phone case.
- 2) If the smartphone fails to read/write configurations via NFC, keep the phone away and back to try again.
- 3) UC51x series can also be configured by dedicated NFC reader, which can be purchased from Milesight IoT.



### 4.1.2 USB Configuration

1. Download ToolBox from [Milesight IoT website](#).
2. Open the case of UC51x and connect the UC51x to computer via type-C port.



3. Open the ToolBox and select type as “General”, then click password to log in ToolBox.  
(Default password: **123456**)

A screenshot of a software window titled "ToolBox Settings". It contains several configuration fields: "Type" (dropdown menu set to "General"), "Serial port" (dropdown menu set to "COM4"), "Login password" (text input field), "Baud rate" (dropdown menu set to "115200"), "Data bits" (dropdown menu set to "8"), "Parity bits" (dropdown menu set to "None"), and "Stop bits" (dropdown menu set to "1"). At the bottom are "Save" and "Cancel" buttons.

4. After logging in the ToolBox, you can click “Power On” or “Power Off” to turn on/off device and change other settings.

A screenshot of the ToolBox main interface. On the left is a dark sidebar with icons and labels: "Status", "LoRaWAN Settings", "Device Settings", and "Maintenance". The main area has a header "Status >" and a "Power On" button. Below is a table of device information:

Model:	UC512-DI-868M
Serial Number:	6415A51585070020
Device EUI:	24e124415a515850
Firmware Version:	01.08
Hardware Version:	1.0
Device Status:	Off
Join Status:	-
RSSI/SNR:	-
Valve1 Status:	-
Counter1:	-
Valve2 Status:	-
Counter2:	-
Battery:	-
Channel Mask:	-
Uplink Frame-counter:	-

## 4.2 Solenoid Valve Control

Solenoid valve can be controlled by ToolBox App or ToolBox software locally.

### Via ToolBox Software:

Click "Open" or "Close" button on the "Status" page to change the status of solenoid valves.

**Status >** Power Off

Model:	UC512-DI-868M
Serial Number:	6415A51585070020
Device EUI:	24e124415a515850
Firmware Version:	01.08
Hardware Version:	1.0
Device Status:	On
Join Status:	Activate
RSSI/SNR:	-42/6
Valve1 Status:	Close <span>Open</span>
Counter1:	-
Valve2 Status:	Open <span>Close</span>
Counter2:	-
Battery:	100%
Channel Mask:	0007
Uplink Frame-counter:	189

### Via ToolBox App:

Click buttons of Valve Status on the "Device->Status" page, then attach the smart phone to device to change the status of solenoid valves.

Status	Setting	Reset
Hardware Version		V1.0
Device Status	ON	<input checked="" type="checkbox"/>
Join Status	Activated	
RSSI/SNR		-35/15
Device Time	2021-02-04 10:35	<span>Sync</span>
Valve 1 Status	Off	<input type="checkbox"/>
Counter 1		0
Valve 2 Status	On	<input checked="" type="checkbox"/>
Counter 2		0
Battery		100 %

## 4.3 LoRaWAN Settings

LoRaWAN settings is used for configuring the transmission parameters in LoRaWAN® network.

Step 1: Go to “**LoRaWAN -> Basic**” of ToolBox software or “**Setting->LoRaWAN Settings**” of ToolBox App to configure join type, App EUI, App Key and other information. You can also keep all settings by default.

Device EUI	<input type="text" value="24E124415A515850"/>
App EUI	<input type="text" value="24E124C0002A0001"/>
Application Port	<input type="text" value="85"/>
Join Type	<input type="text" value="OTAA"/>
LoRaWAN Version	<input type="text" value="V1.1.0"/>
Application Key	<input type="text" value="*****"/>
Spread Factor	<input type="text" value="SF10-DR2"/>
Confirmed Mode	<input type="checkbox"/>
Rejoin Mode	<input checked="" type="checkbox"/>
Set the number of packets sent	<input type="text" value="32"/> packets
ADR Mode	<input checked="" type="checkbox"/>
TXPower	<input type="text" value="TXPower0-16 dBm"/>

Parameters	Description
Device EUI	Unique ID of the device which can also be found on the label.
App EUI	Default App EUI is 24E124C0002A001.
Application Port	The port used for sending and receiving data, default port is 85.
Join Type	OTAA and ABP mode are available.
LoRaWAN Version	V1.0.2, V1.0.3, V1.1 are available.
Application Key	Appkey for OTAA mode, default is 5572404C696E6B4C6F52613230313823.
Device Address	DevAddr for ABP mode, default is the 5 <sup>th</sup> to 12 <sup>th</sup> digits of SN.
Network Session Key	Nwkskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Application Session Key	Appskey for ABP mode, default is 5572404C696E6B4C6F52613230313823.
Spread Factor	If ADR is disabled, the device will send data via this spread factor.
Confirmed Mode	If the device does not receive ACK packet from network server, it will resend

	data 3 times at most.
Rejoin Mode	<p>Reporting interval <math>\leq</math> 30 mins: device will send specific mounts of LoRaMAC packets to check connection status every 30 mins; If no reply after specific packets, the device will re-join.</p> <p>Reporting interval <math>&gt;</math> 30 mins: device will send specific mounts of LoRaMAC packets every to check connection status every reporting interval; If no reply after specific packets, the device will re-join.</p>
ADR Mode	Allow network server to adjust datarate of the device.
Tx Power	Tx power of the device.

**Note:**

- 1) Please contact sales for device EUI list if there are many units.
- 2) Please contact sales if you need random App keys before purchase.
- 3) Select OTAA mode if you use Milesight IoT cloud to manage devices.
- 4) Only OTAA mode supports rejoin mode.

Step 2: Go to “**LoRaWAN -> Channel**” of ToolBox software or “**Setting->LoRaWAN Settings**” of ToolBox APP to select supported frequency and select channels to send uplinks. Make sure the channels match the LoRaWAN® gateway.

<input type="checkbox"/>	Index	Frequency/MHz	Max Datarate	Min Datarate
<input checked="" type="checkbox"/>	0	868.1	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	1	868.3	5-SF7BW125	0-SF12BW125
<input checked="" type="checkbox"/>	2	868.5	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	3	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	4	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	5	0	5-SF7BW125	0-SF12BW125
<input type="checkbox"/>	6	0	5-SF7BW125	0-SF12BW125

If frequency is one of CN470/AU915/US915, you can enter the index of the channel that you want to enable in the input box, making them separated by commas.

**Examples:**

1, 40: Enabling Channel 1 and Channel 40

1-40: Enabling Channel 1 to Channel 40

1-40, 60: Enabling Channel 1 to Channel 40 and Channel 60

All: Enabling all channels

Null: Indicates that all channels are disabled

Support Frequency : AU915

Enabled Channel Index: 0-71

Channel Index	Frequency/MHz	Channel Spacing/MHz	BW/kHz
0 - 15	915.2 - 918.2	0.2	125
16 - 31	918.4 - 921.4	0.2	125
32 - 47	921.6 - 924.6	0.2	125
48 - 63	924.8 - 927.8	0.2	125
64 - 71	915.9 - 927.1	1.6	500

**Note:**

For -868M model, default frequency is EU868;

For -915M model, default frequency is AU915.

## 4.4 Solenoid Settings

Go to **"General->Device Settings->Basic"** of ToolBox software or **"Setting->General Settings"** of ToolBox App to change the reporting configurations.

Device Type UC512

Reporting Interval 20 min

Solenoid Valve Wiring Switch ☒

Data Reporting All

Device Return to Power Supply State Return to previous working state

Class Type Class A

Response Time 600 s

Change Password ☐

Parameters	Description
Reporting Interval	Reporting interval of transmitting data to network server.Default: 20min
Solenoid Valve Wiring Switch	After this parameter is enabled, when users connect the solenoid cable to any solenoid interface, the device will turn on automatically.
Data Reporting	Select the contents to report to network server. All: Report all interface status; Valve 1& Water Meter 1: Report the status of the Valve 1 interface and data of GPIO1; Valve 2& Water Meter 2: Report the status of the Valve 2 interface and data of GPIO2.
Device returns to the power supply state	If the device loses power and return to power supply, the device will be on or off according to this parameter.
Class Type	Working mode of LoRaWAN <sup>®</sup> device. UC511: Class A and Class C are available; UC512: Class A.
Response Time	When the device works under Class A mode, it only receives control commands every reporting interval comes. In order to shorten the delay time of control, the device will send blank package to allow to receive the control commands every Response Time interval. <b>Note:</b> The shorter the response time, the shorter the battery life.
Change Password	Change the password for ToolBox App or software to read/write this device.

**Note:**

- 1) When device connects to network server of Milesight gateway, the blank package will take up the frame count but not show on the package list.
- 2) The device only starts counting after receiving more than 5 pulses.
- 3) Reboot or re-join will not affect the counting.

## 4.5 Maintenance

### 4.5.1 Upgrade

#### ToolBox Software:

1. Download firmware from [www.milesight-iot.com](http://www.milesight-iot.com) to your PC.
2. Go to “**Maintenance -> Upgrade**” of ToolBox software, click “**Browse**” to import firmware and upgrade the device. You can also click “**Up to Date**” to search for the latest firmware of the device and upgrade.

### Maintenance >

The screenshot shows the 'Maintenance >' section with two tabs: 'Upgrade' (selected) and 'Backup and Reset'. Under the 'Upgrade' tab, the following information is displayed:

- Model: UC512-DI-868M
- Firmware Version: 01.08
- Hardware Version: 1.0
- Domain: Beijing Server (dropdown menu)
- FOTA: Up to date (button) | Your device is up to date.
- Update Locally: [text input field] | Browse (button) | Upgrade (button)

### ToolBox App:

1. Download firmware from [www.milesight-iot.com](http://www.milesight-iot.com) to your smartphone.
2. Open ToolBox App and click “Browse” to import firmware and upgrade the device.

### Note:

- 1) Operation on ToolBox is not supported during the upgrade.
- 2) Only Android version ToolBox supports the upgrade feature.

The screenshot shows the 'ToolBox App' interface with a blue header bar containing a menu icon and the device name 'UC512-DI-868M'. Below the header are three tabs: 'Status', 'Setting', and 'Maintenance' (selected). The 'Maintenance' tab displays the following information:

- SN: 6415A51585070020
- Model: UC512-DI-868M
- Firmware Version: V1.12
- Hardware Version: V1.0
- Manual Upgrade: [text input field] | Browse (button)

### 4.5.2 Backup

UC51x devices support configuration backup for easy and quick device configuration in bulk.

Backup is allowed only for devices with the same model and LoRa frequency band. Please select one of following methods to backup device:

#### ToolBox Software:


1. Go to "Maintenance->Backup and Reset", click "Export" to save current configuration as json format backup file.
2. Click "Browse" to select backup file, then click "Import" to import the configurations.

The screenshot shows the 'Backup and Reset' tab selected in the ToolBox Software interface. The interface has a top navigation bar with 'Upgrade' and 'Backup and Reset' tabs. Below the navigation bar, there are three main sections: 'Config Backup' with an 'Export' button, 'Config File' with a text input field, a 'Browse' button, and an 'Import' button, and 'Restore Factory Defaults' with a 'Reset' button.

#### ToolBox App:

1. Go to "Template" page on the App and save current settings as a template. You can also edit the template file.
2. Select this template and attach to another device to write configuration.






#### 4.5.3 Reset to Factory Default


Please select one of following methods to reset device:

**Via Hardware:** Open the case of UC51x and hold on power button more than 10s.

**Via ToolBox Software:** Go to "Maintenance->Backup and Reset" to click "Reset".



**Via ToolBox APP:** Go to "Device->Maintenance" to click "Reset", then attach smart phone with NFC area to UC51x to complete reset.

 **UC512-DI-868M**

[Status](#) [Setting](#) [Maintenance](#)

SN

6415A51585070020

Model

UC512-DI-868M

Firmware Version

V1.12

Hardware Version

V1.0

Manual Upgrade

Browse

Restore Factory Default


Reset



## 5. Milesight IoT Cloud Management

UC51x series can be managed by Milesight IoT Cloud platform. Milesight IoT cloud is a comprehensive platform that provides multiple services including device remote management and data visualization with the easiest operation procedures. Please register a Milesight IoT Cloud account before operating following steps.


### 5.1 Add UC51x to Cloud

1. Ensure Milesight LoRaWAN<sup>®</sup> gateway is online in Milesight IoT Cloud. For more info about connecting gateway to cloud please refer to gateway's user guide.



Status	Name	Associated Devices (Joined / Not Joined / Failed)	Last Updated
	UG Gateway 621793129987	0 / 0 / 0 <a href="#">Detail</a>	a few seconds ago
	UG Gateway 6222A3243835	0 / 1 / 0 <a href="#">Detail</a>	2021-02-03 09:41


2. Go to "My Devices" page and click "+New Devices". Fill in the SN of UC51x and select associated gateway.




The "Add Device" dialog box contains the following fields:

- \* SN: 6415A51585070020
- \* Name: UC511
- \* Associated Gateway: UG Gateway
- \* Device EUI: 24e124415A515850
- \* Application Key: 5572404c696e6b4c6f52613230313823

Buttons: Cancel, Confirm

3. Default working mode of UC511 devices is Class C. If you need to change the mode of UC511 to Class A, click  and go to "Basic Settings" to change mode to Class A.




The "Basic Settings" page for UC511 shows the following configuration:

- Name: UC511
- Application Key: 5572404c696e6b4c6f52613230313823
- LoRaWAN Class: classA (highlighted with a red box)
- Description: (empty)

Buttons: Refresh, Share


Besides, configure the unit of per pulse if you connect the water meter.



The "Basic Settings" page for UC511 shows the following configuration:

- Description: (empty)
- \* Unit Per Pulse: 1 gal (highlighted with a red box)
- \* Reporting Interval: 20 min
- Device Offline Alarm: ☒

Buttons: Refresh, Share

4. Click  and go to "Interface Settings" to select used interfaces and customize the name and thresholds.

Devices / UC511 / Interface Settings


Basic Settings Interface Settings Maintenance Log Refresh Share

Enable	Name	Type	Current Value	Alarm Threshold
<input checked="" type="checkbox"/>	Valve 1	Valve	Closed	= Disable
<input checked="" type="checkbox"/>	Valve 2	Valve	Closed	= Disable

Enable	Name	Current Value	Unit	Alarm Threshold
<input type="checkbox"/>	Valve 1 - Last flow volume	0	gal	
<input checked="" type="checkbox"/>	Valve 1 - Total flow volume	0	gal	
<input type="checkbox"/>	Valve 2 - Last flow volume	0	gal	
<input checked="" type="checkbox"/>	Valve 2 - Total flow volume	0	gal	

## 5.2 Solenoid Valve Control

Solenoid valve can be controlled by Milesight IoT cloud webpage or App.

1. Click  to open the solenoid valve and configure the duration.

Devices Gateways +

Search

Normal 1 Alarm 0 Offline 3 Inactive 0 + New Devices


Status	Name	Interface Status	Update Time	
<input type="checkbox"/>	UC511 6415A51585070020	<b>Closed</b> Valve 1 <b>Open</b> Valve 2	<b>0gal</b> Valve 1 - Last flow volume <b>0gal</b> Valve 2 - Last flow volume	12 minutes ago
<input type="checkbox"/>	UC501 6412A5196409	GPIO_1 GPIO_2	Temperature	

### OpenValve 1


\* Please set the duration of operating:  min

Cancel Open

You can also add a switch on the dashboard to control the status of solenoid valves.




**Note:** If working mode of UC51x is Class A, control commands will delay until the time icon disappear.



2. Go to "Triggers" page to add actions to trigger the solenoid valve to open for a period of time or a specific volume of water.

**Note:** Water volume control is only worked when you connect water meter to UC51x device.



## 6. Device Payload

UC51x Series use the standard Milesight IoT payload format based on IPSO. Please refer to the ***UC51x Series Communication Protocol***; for decoders of Milesight IoT products please click [here](#).

**-END-**