

Table of Contents

1. Packing List	2
2. Hardware Introduction	3
3. Interfaces	4
1. Installation	4
5. OpenVision Server Software Wizard	8



1. Packing List /



OpenVision Server x1



Heat Conduction Gasket x2



HDMI Adapter Cable



Ethernet Cable x1



Cross Screwdriver x1



VESA Mounting Bracket Screw ① x4



VESA Mounting Bracket Screw (2) x4



SSD Column Standoff x2



SSD Mounting Screw x2





Quick Start Guide x1

Bracket Version Only Materials:





Mounting Bracket (with silicone pad attached) x2

35mm DIN Rail Mounting Clip x1

Mounting Bracket Screw ① x8




Mounting Bracket

600 600 600 600

DIN Mounting Screw 2 x4 Bracket Screw x2

2. Hardware Introduction






www.milesight.com www.milesight.com



3.Interfaces



- 1. 2*Indicator Light
- 2. Reset Button
- 3. DC12V


4. Alarm I/O 7. 1*USB2.0

- 5. PoE Port 8. Audio
- 6. 3*USB3.0 9. 2*Micro HDMI Port
- 10. Grounding Hole(Grounding Screw Pre-installed)

4.Installation /

Installation of the VESA Mount

Secure the VESA mount to the device's rear panel and tighten the four screws to complete the installation.




Note:

The VESA mount is not included in the package and should be purchased separately.


Installation of the Bracket Mount (For Bracket Version)

Use a cross screwdriver to install the two brackets on the sides.




Installation of the DIN Rail Mount (For Bracket Version)

Use a cross screwdriver to tighten and secure the DIN mounting bracket to the back.




Installation of SSD (Optional)

Step 1: Use a cross screwdriver to remove the screws on the rear panel in an anticlockwise direction, then open the rear panel.




Step 2: Place the SSD(s), and tighten the screws to secure the SSD(s). 2 screws for each SSD.




Note:

Up to two SSDs can be installed.

Step 3: Attach the heat conduction gasket(s) onto the SSD(s).



Step 4: Replace the rear panel, and screw them back in place.



5. OpenVision Server Software Wizard

Step 1: Insert the SSD and power on the device.

Step 2: Activate and configure the device.

Open Smart Tools and locate the device by its default IP address (192.168.5.190). Select and activate the device, then modify its IP address. You can then double-click to access the device web interface for further configuration.

Step 3: Activate the NX Server.

On the device's web interface, click "Open VMS Edge" button to access the NX Server web page. Then create a new system, and complete the initialization of the NX Server.



Step 4: Connect to the NX Server.

Open the NX Witness Client on your computer and log in using the device's current IP address to connect to the server.

Note:

Users can also change the default system password in the device's web interface, then connect the device to a monitor and log into the Ubuntu system using the new password. Open the NX Witness Client and connect to the server using the default IP address (127.0.0.1:7001) to complete the creation and activation of the server.